

How To Delete Data After Screening:

Plus Optix Camera:

1. Turn on camera
2. Insert USB drive into camera
3. Press the settings icon in lower left corner of screen
4. There is a trash can in the fourth row, press it
5. Click green check mark
6. Remove the USB drive
7. Insert USB drive into a computer
8. Open the USB drive to view files
9. Select a file titled Plusoptic-V6-backup.
10. Delete the file
 - a. On a PC press the delete button
 - b. On a Mac, select the file and move to the trash